

Single Phase Element Connection.

Step 1: Remove the cable gland for the corresponding element.



Step 2: Insert the connection end into the cable gland as shown.



Step 3: Insert the gland into the panel and tighten to secure the cord.



Step 4: Connect the white and black wires to the bottom of the element contactor.



Step 5: Attach the ground wire (green) directly to the back panel



