

Default PID programming:

Code 0089

Inty = P10.0

outy = 2

CorF = 1 (use 0 for celsius)

All other setting leave at default

Code 0036

P = .1

I = 2

D = 0

Souf = .3

All other settings leave at default